

EN- GENERAL INFORMATION

Thank you for purchasing your LEVO™ Series T device.

Please read these instructions carefully. They contain important information to help you use your device correctly and safely.

LEVO™ features a high-precision mechanical system, manufactured using quality materials and designed to provide reliable, long-lasting performance when used and maintained correctly.

LEVO™ devices allow you to organize and select conventional keys through a simple automatic mechanism, keeping them neatly stored in a compact, comfortable and easy-to-use device.

Their articulated arms make it easy to insert, remove and exchange keys between LEVO™ devices or conventional key rings using the appropriate accessories.

EN- INSTRUCTIONS

KEY PREPARATION. To use your keys with LEVO™, the head of each key must first be adapted, as shown in **Figure 1**.


This adaptation can be carried out through our KeyAdaptor service, available at levo-smart.com.

To use this service, you must obtain new, uncut key blanks compatible with your locks and send them to us following the service instructions. Once the adapted keys have been returned, you can take them to your usual locksmith to have them duplicated from your original keys.



KEYADAPTOR. Once your keys have been adapted and duplicated, attach the KeyAdaptor accessory to the head of each key, as shown in **Figure 2**.


If the key blade has an irregularly shaped end, position it so that the toothed side faces the inside of the LEVO™ device housing.



CAP. The CAP accessory allows keys adapted for LEVO™ to be used with conventional key rings.

To install it, remove the pin from the CAP accessory and insert the key blade into its housing, as shown in **Figure 3**.

Then reinsert the pin and make sure it is securely fastened before using the key.



LEVO™ DEVICE. Press the button corresponding to the key you wish to use. The articulated arm will automatically extend, giving you access to the key.

To install a key:

1. Slide the side button on the articulated arm, as shown in **Figure 4**.




2. Insert the adapted key with the KeyAdaptor accessory into its housing, as shown in **Figure 5**.

WARNING: Make sure the key is positioned exactly as indicated. If the key blade has an irregularly shaped end, ensure that the toothed side faces the inside of the LEVO™ housing.



3. Slide the side button on the arm again, as shown in **Figure 6**, to secure the key. Make sure it is firmly locked in place before use.



To replace a key, repeat the procedure above, first removing the installed key.

IMPORTANT: If a lock offers resistance, do not force the key or the LEVO™ mechanism. Check that the key is correctly positioned and that the lock is functioning properly.

EN- WARRANTIES

Your LEVO™ Series T device is covered by a three-year statutory warranty from the date of delivery, in accordance with current Spanish consumer protection legislation.

LEVO™ features a precision mechanism designed to provide reliable, long-lasting performance. To keep your device in good condition, follow the instructions in this manual.

Avoid exposing the device to corrosive environments, excessive humidity, liquids or other conditions that may damage its mechanical components.

The statutory warranty covers any lack of conformity under the terms established by applicable law. Damage resulting from accidents, impacts, unauthorized modifications or improper use does not, in itself, constitute a manufacturing defect.

If your device develops a fault, please contact our customer service team at levo-smart.com.

In the event of a lack of conformity, consumers may request free repair or replacement of the product and, where legally applicable, a price reduction or termination of the contract.

This warranty does not limit the consumer's statutory rights under applicable law.

LEVO™ is a registered trademark of LEVO KEY HOLDERS, S.L.

Made in Spain.